

GPFM115 SERIES INSTALLATION INSTRUCTIONS

MODEL NUMBERS: GPFM115-X-YYY-C G, where X represents the output voltage, which may be any number from 3.3 through 48, -YYY is a value added option not related to Safety. May be followed by optional Suffixes: -C, when used, indicates optional cover/fan is provided, “G” indicates compliance with RoHS.

RATINGS:

Input: 100-240 V ac, 2.3 A, 50/60 Hz

Output:

20 A or 115 W maximum, with a minimum of 150 LFM without cover, or with suffix -C.

12 A or 80 W maximum, with no airflow and no cover.


Fan output is 12 V dc, 0.1 A (provided for connection of fan only)

- Notes:
1. Maximum ambient temperature for rated output power is 50 °C.
 2. Maximum Operating Relative Humidity 96%, no condensation.
 3. Storage: -40 to +85 °C. Units should be allowed to warm-up under non-condensing conditions before application of power.

CERTIFICATION: All models are Certified to be in compliance with the applicable requirements of UL 2601-1, CSA 22.2 No. 601.1, EN 60601-1, and IEC 60601-1.

CLASSIFICATION:

(In accordance with sub-clause 5 of IEC 60601-1)	(5.1) Protection against electric shock = Class I
	(5.2) Degree of protection against electric shock = Not acceptable for applied part without additional isolation (contact factory for details)
	(5.3) Protection against harmful ingress of water = Ordinary (no protection)
	(5.5) Have not been evaluated for use in the presence of a flammable anaesthetic mixture with air, oxygen, or nitrous oxide. This evaluation is to be made on the end equipment by the OEM.
	(5.6) Mode of operation = Continuous

 **SAFETY DECLARATION:** SL Power Electronics. declares under our sole responsibility that all models listed above are in conformity with the applicable requirements of EN60950 following the provisions of the Low Voltage Directive 2006/95/EC.

GROUNDING: Protection Class I requires that the ground terminal be bonded to Protective Earth in the end application. Using this terminal for the primary system earthing terminal is not recommended.

OUTPUTS: Output common or return should be connected to Protective Earth in the end application. The output is intended for Protectively Earthed Signal Output and Intermediate Circuits only. The output is not acceptable for patient connection without additional isolation. The DC output is SELV under normal and single fault conditions.

OVERVOLTAGE PROTECTION: The output is monitored for an overvoltage condition. In some applications where an overvoltage condition could result in a hazard as defined in applicable safety standards, redundant or additional overvoltage protection may be required. Consult factory for details.

CAUTION: When performing Dielectric Strength Tests, catastrophic failure of the unit may result if a Dielectric Strength test voltage greater than 1800 V ac is applied between primary and secondary circuits. The components providing isolation from primary to secondary cannot be tested while installed in the power supply without overstressing basic (primary to ground) insulation. All isolating components are individually 100 % tested at 4800 V ac prior to installation.






GPFM115 SERIES INSTALLATION INSTRUCTIONS

TEMPERATURES: The maximum operating temperatures of certain safety components, as defined in the applicable safety standards, must not be exceeded after installation to preserve the intended safety. The output power, ambient air temperature and the availability, amount, direction and/or restriction of airflow influence the temperatures of these components.

OVERCURRENT PROTECTION: The internal fuse is located in the phase lead only. EN 60601-1 requires that both supply leads (phase and neutral) be protected against overcurrent. Complete overcurrent protection must be provided in the host equipment. Fuse ratings must not exceed that specified for the internal fuse, must meet the requirements of EN 60601-1, and be acceptable for the country in which the host equipment is to be installed.

WARNING! RISK OF FIRE! A blown internal fuse is an indication of catastrophic failure of circuit component(s). Refer to fuse marking on the supply for rating. Repair must be performed by Condor authorized personnel.

WARNING! SHOCK HAZARD! Dangerous voltages are present on some components, printed wiring traces and heatsinks.

EXPLANATION OF SYMBOLS	
	Alternating Current
	Direct Current
	Attention, Consult Accompanying Documents
	Attention, Dangerous Voltages
	Earth (Ground)

CONNECTIONS

J1 Pin	AC Input	J3 Pin	DC Output	J2 Pin	DC Output	J4	12 V Fan Output
1	Line	1	+ Output	1	Power Fail	2	Fan Return
3	Neutral	2	+ Output	2	- Sense	1	+ Fan
5	Ground	3	+ Output	3	+ Sense		
		4	+ Output	4	Common		
		5	- Output				
		6	- Output				
		7	- Output				
		8	- Output				

MATING CONNECTORS	
J1	Amp 640250-5 Contact 770476-1
J2	Amp MTA-100 Receptacle
J3	Amp 640250-8 Contact 770476-1
J4	Amp MTA-100 Receptacle

CAUTION: Do not exceed 5 A per contact on J3.

SL Power Electronics will not be liable for the safety, reliability or performance of these power supplies if a) any changes, modifications or repairs are carried out by other than authorized agents of SL Power Electronics, or b) the installation of the supply is not in accordance with these installation instructions and the applicable UL, CSA, and EN/IEC safety standards.